

# Using Meridian/P with the Ethernet adapter board


The following instructions show you how to add Ethernet to the Meridian/P Micro Development Board. The Ethernet board used is available from Device Solutions. Software is available from:

[www.devicesolutions.net/Support/Download.aspx](http://www.devicesolutions.net/Support/Download.aspx)

1. Solder a 0.1" pin header (supplied with Meridian/P) into the EXP1 connector socket



2. **IMPORTANT** Cut off pin 17. This is a 3.3V pin but is connected to 5V on the Ethernet adapter. If you do not cut this pin you will end up shorting the 5V and 3.3V rails together and will destroy you Meridian/P board.



3. Attach the Ethernet board.

